



HTC Rhyme Volume Button Replacement

Written By: Frederick





TOOLS:

- [Spudger](#) (1)
- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)



PARTS:

- [HTC Rhyme Metal Frame](#) (1)

Step 1 — Removing Back Cover




- Slide the bottom back cover off of the phone.

Step 2




- Locate the four screws on the plastic cover and unscrew them.

Step 3




- Pry the sticker off from the sides.
- ⓘ You can use a metal spudger to do this.
- Peel the sticker off with your hands.

Step 4 — Remove the plastic cover





- Remove the plastic cover using your hands.

Step 5





- Remove the yellow ribbon.

Step 6




- Lift up the blue flaps underneath the battery.
- Lift up the black flap at the top of the phone.
- Lift up the black flap at the bottom of the phone.

Step 7 — Remove the Motherboard



- Remove all 4 screws.
- Carefully remove the motherboard with your hands.

Step 8 — Removing the back plastic casing



- Pry the back plastic casing off with your hands.

Step 9



- Use the tip of a screwdriver to push the button out of the panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-28 12:46:10 AM.